



**Notice pour l'installation du module TCM-01
(module de communication et d'horloge pour l'XTS)**
**Instruction for the installation of the module TCM-01
(communication and internal clock module for XTS)**
**Hinweis für die Installation des Moduls TCM-01
(Kommunikationsmodul und Uhr für den XTS)**
**Instrucciones para la instalación del módulo TCM-01
(módulo de comunicación y reloj para XTS)**

1. Contenu / Content / Inhalt / Contenido

A.



D.



B.




E.



C.





**2. Avant l'installation du module / Before module installation /
Vor der Installation des Moduls / Antes de la instalación del módulo**





3. Installation / Installation / Installation / Instalación



A



B



C




D



E



F**G**

4. Pour plus d'informations / For more information / Für weitere Informationen/ Para más informaciones



Toutes autres informations relatives l'utilisation du module de communication et d'horloge TCM-10 pour l'XTS se trouvent dans le manuel Xtender.

More information related to the use of the communication and internal clock module TCM-10 for XTS is in the Xtender user manual.

Alle weiteren wichtigen Informationen zur Anwendung dieses Kommunikationsmoduls und der Uhr TCM-10 für den XTS finden Sie im Benutzerhandbuch des Xtender.

Encontrará todas las informaciones relativas al uso del módulo de comunicación y reloj TCM-01 para el XTS en el manual Xtender.